


SQUARE 8 SEATER PICNIC TABLE ASSEMBLY INSTRUCTIONS



1 Prepare your workspace before you begin, place the table top to one side and lay out all of the remaining pieces as shown in the image below. Work on a flat, level surface to ensure the finished table sits evenly once assembled.

Each part is labelled to help you match the correct faces together - "A" to "A", "B" to "B", "C" to "C", and so on. Take a moment to ensure the markings are visible and correctly aligned. The table legs are also marked "TOP"; make sure this side is facing upwards before moving on.



2 Match and align components. Check again that all corresponding faces of the legs and seat bases are paired correctly - "A" to "A", "B" to "B", "C" to "C". Correct alignment at this stage is important, as it ensures the seat bases and table legs sit flush when bolted together and prevents any wobble later.



3 Assemble the frame. Once you're happy with the layout, begin bolting the legs to the seat bases using the M8 x 160mm bolts, washers and nuts provided. Use two bolts per leg, tightening them by hand or with a spanner. Do not over-tighten at this stage - leave a little movement in the frame so that adjustments can be made easily when the rest of the table is fitted.

Tip: Lightly tighten all bolts first and fully secure them once the full table is assembled and level.

SQUARE 8 SEATER PICNIC TABLE ASSEMBLY INSTRUCTIONS



4 Fit the table top before lifting the table top into place, check the corresponding alignment marks on both the legs and the underside of the table top. These markings ensure the top is positioned the correct way around. Once aligned, carefully lift the table top onto the legs, keeping it steady and level as you set it down.

Tip: It's best to have two people for this stage to avoid strain or accidental damage.



5 Secure the table top to the frame. Make sure each leg sits firmly in the corners of the table frame. Using the M8 x 150mm bolts, washers, and nuts provided, secure the table top to the legs. Check that each bolt passes cleanly through the pre-drilled holes before tightening. Lightly tighten all bolts first to allow for minor adjustments before final tightening.



6 Final adjustments and finishing touches. Once you're happy with the position of all legs, seat bases, and the table top, go back and fully tighten all nuts and bolts to ensure a secure fit. Finally, push the domed nut caps onto each bolt to cover the exposed ends for a neat, finished appearance and added safety. Your picnic table is now ready for use.

CARE & MAINTENANCE

To keep your Cladco picnic table looking its best:

- ✓ Check all nuts and bolts periodically and retighten if necessary, especially after periods of heavy use or extreme weather.
- ✓ Clean with mild soapy water and a soft brush or cloth; avoid using harsh chemicals or abrasive pads.
- ✓ If your table is positioned outdoors year-round, we recommend occasionally moving or rotating it to prevent uneven weathering.

Following these simple steps will help maintain your table's appearance and ensure long-lasting performance.

